

## PROCEDURE



### 1.INSTALL FUEL PRESSURE PULSATION DAMPER ASSEMBLY

23270

- a. Apply a light coat of spindle oil or gasoline to a new O-ring and install the O-ring to the fuel pressure pulsation damper assembly.
- b. Install the fuel pressure pulsation damper assembly to the fuel delivery pipe sub-assembly.
- c. Install the fuel pressure regulator holder to the fuel pressure pulsation damper assembly.



### 2.CONNECT CABLE TO NEGATIVE BATTERY TERMINAL



### 3.INSPECT FOR FUEL LEAK

[Click here](#)Engine / Hybrid System>1GR-FE FUEL>FUEL INJECTOR>INSTALLATION