

## PROCEDURE

### 1.INSTALL OIL PRESSURE SENDER GAUGE ASSEMBLY

83520

- a. Apply adhesive to 2 or 3 threads of the oil pressure sender gauge assembly.

**Adhesive:**

**Toyota Genuine Adhesive 1344, Three Bond 1344 or equivalent**

**NOTICE:**

Do not apply adhesive to the oil inlet port of the oil pressure sender gauge assembly.

- b. Using a 27 mm deep socket wrench, install the oil pressure sender gauge assembly.

**Torque:**

**15 N\*m (153 kgf\*cm, 11 ft.\*lbf)**

**NOTICE:**

Do not start the engine within 1 hour of installation.

- c. Connect the oil pressure sender gauge connector.

### 2.INSPECT FOR OIL LEAK

[Click here](#)Engine / Hybrid System>1GR-FE LUBRICATION>OIL AND OIL FILTER>REPLACEMENT

### 3.CHECK ENGINE OIL LEVEL

[Click here](#)Engine / Hybrid System>1GR-FE LUBRICATION>LUBRICATION SYSTEM>ON-VEHICLE INSPECTION