

**CAUTION / NOTICE / HINT****HINT:**

- Use the same procedure for RHD and LHD vehicles.
- The procedure listed below is for LHD vehicles.

**PROCEDURE****1.INSTALL SPIRAL CABLE SUB-ASSEMBLY****84306****NOTICE:**


- Do not replace the spiral cable sub-assembly with the battery connected and the ignition switch on (IG).
- Do not rotate the spiral cable with the battery connected and the ignition switch on (IG).

- Check that the ignition switch is off.
- Check that the cable is disconnected from the negative (-) battery terminal.

**CAUTION:**


Wait at least 90 seconds after disconnecting the cable from the negative (-) battery terminal to disable the SRS system.

- Check that the front wheels are facing straight ahead.

**d.**

Attach the 3 claws to install the spiral cable sub-assembly.

**NOTICE:**



When replacing the spiral cable sub-assembly with a new one, remove the lock pin before installing the steering wheel assembly.

- e. Connect each connector.
- f. Connect the airbag connector and check that the slider is in the lock position.

**NOTICE:**

When handling the airbag connector, take care not to damage the airbag wire harness.

**HINT:**

If the slider is not in the lock position, the airbag connector is not completely connected. Disconnect the airbag connector, check the airbag connector and spiral cable sub-assembly terminals and connector housings for deformation or foreign matter, and then reconnect the airbag connector.



**2.INSTALL UPPER STEERING COLUMN COVER**

**45286B**

[Click here](#)Steering>STEERING COLUMN>STEERING COLUMN ASSEMBLY>INSTALLATION



**3.INSTALL LOWER STEERING COLUMN COVER**

**45287**

[Click here](#)Steering>STEERING COLUMN>STEERING COLUMN ASSEMBLY>INSTALLATION



**4.ADJUST SPIRAL CABLE SUB-ASSEMBLY**

**84306**

**NOTICE:**


Do not adjust the spiral cable sub-assembly with the battery connected and the ignition switch on (IG).

- a. Check that the ignition switch is off.
- b. Check that the cable is disconnected from the battery negative (-) terminal.

**CAUTION:**

Wait at least 90 seconds after disconnecting the cable from the negative (-) battery terminal to disable the SRS system.

c.




*1	Check Window
*2	Orange Colored Roller
*3	Matchmark

Check the check window shown in the illustration.

**OK:**

**When the spiral cable sub-assembly is centered, the connector is at the top, the orange colored roller can be checked from the check window and the matchmarks are aligned.**

d.



P

	Counterclockwise
--	------------------


If the spiral cable sub-assembly is not centered, center it.


- i. Rotate the spiral cable sub-assembly counterclockwise slowly by hand until it stops.

**NOTICE:**

Do not turn the spiral cable sub-assembly using the airbag wire harness.

ii.



*1	Check Window
*2	Orange Colored Roller
*3	Matchmark
	Clockwise

Rotate the spiral cable sub assembly 2.5 times clockwise from the lock position and check the check window and matchmarks.

**OK:**

**When the spiral cable sub-assembly is centered, the connector is at the top, the orange colored roller can be checked from the check window and the matchmarks are aligned.**

If the spiral cable sub-assembly cannot be centered, it is possible that the spiral cable sub-assembly is malfunction. Replace the spiral cable sub-assembly with a new one.



## 5.INSTALL LOWER INSTRUMENT PANEL FINISH PANEL ASSEMBLY

55480D

Click here[Vehicle Interior>INTERIOR PANELS / TRIM>INSTRUMENT PANEL SAFETY PAD>INSTALLATION](#)



## 6.INSTALL STEERING WHEEL ASSEMBLY

45100

Click here[Steering>STEERING COLUMN>STEERING WHEEL>INSTALLATION](#)



## 7.CONNECT CABLE TO NEGATIVE BATTERY TERMINAL



## 8.PERFORM DIAGNOSTIC SYSTEM CHECK

Click here[Vehicle Interior>SUPPLEMENTAL RESTRAINT SYSTEMS>AIRBAG SYSTEM>DTC CHECK / CLEAR](#)



## 9.CHECK SRS WARNING LIGHT

Click here[Vehicle Interior>SUPPLEMENTAL RESTRAINT SYSTEMS>AIRBAG SYSTEM>DIAGNOSIS SYSTEM](#)