

CAUTION / NOTICE / HINT

HINT:

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.

PROCEDURE



1.INSPECT REAR SHOCK ABSORBER ASSEMBLY LH

48540

- a.** Compress and extend the shock absorber rod 4 or more times and check the operating sound and resistance.

Standard:

The operating sound and resistance are normal.

If there is any abnormality, replace the rear shock absorber with a new one.