

CAUTION / NOTICE / HINT

HINT:


- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.

PROCEDURE

1.REMOVE LEAF SPRING DYNAMIC DAMPER (w/ Dynamic Damper)

48375

a.




Remove the bolt, nut and dynamic damper.

2.REMOVE REAR SPRING PIN BUSH (for 1VD-FTV 76, 78 Series)


48210B

a.




Using a chisel and hammer, tap out the bush (inner side).

b.



Using a chisel and hammer, pry the flange of the bush (outer side) outward.



Using SST, remove the bush (outer side).

SST

09950-00020 09950-40011 09950-60010 09950-50013 (09951-04020, 09953-04030, 09957-04010, 09952-05010, 09954-05041, 09955-05040)

■ **3.REMOVE REAR SPRING SHACKLE BUSH (except 1VD-FTV 76, 78 Series)**


48210Q

- a. Remove the 2 bushes from the rear spring.


■ **4.DISASSEMBLE REAR SPRING ASSEMBLY LH**

48220

- a. Secure the rear leaf spring assembly in a vise between aluminum plates.



Remove the hexagon bolt, washer and rear spring clip bolt case from the rear leaf spring.




Using a brass bar and hammer, pry open the spring clip of the rear leaf spring.

NOTICE:

Do not damage the leaf spring.

d.



Remove the nut and center bolt.

e. Remove the rear spring silencers from the leaf spring.