


## PROCEDURE

## 1.DRAIN TRANSFER OIL




*1	No. 1 Transfer Case Plug (Filler Plug)
*2	Transfer Drain Plug

- a. Remove the No. 1 Transfer Case Plug (Filler Plug) and No. 1 transfer case gasket.
- b. Remove the transfer drain plug and transfer drain plug gasket, and drain the transfer oil.
- c. Install a new transfer drain plug gasket to the transfer drain plug and then install the transfer drain plug.

**Torque:****37.24 N\*m (380 kgf\*cm, 27 ft.\*lbf)**

## 2.ADD TRANSFER OIL



*a	0 to 5.0 mm (0 to 0.196 in.)
----	------------------------------

Pour oil so that the oil level is between 0 to 5.0 mm (0 to 0.196 in.) from the bottom lip of the filler plug hole.

**Transfer Oil:**

Oil grade	Oil viscosity
API GL-4 or GL-5	SAE 75W-90

**Standard capacity:****1.5 liters (1.6 US qts, 1.3 Imp. qts)****NOTICE:**

- When adding oil, pour it slowly.
- Add oil a little at a time, waiting several minutes between each addition of oil.
- Too much or too little oil will lead to transfer problems.

- b.** Wait approximately 5 minutes and check that the oil level has not changed.
- c.** Install a new No. 1 transfer case gasket to the No. 1 Transfer Case Plug (Filler Plug) and then install the No. 1 Transfer Case Plug (Filler Plug).

**Torque:**

**37.24 N\*m (380 kgf\*cm, 27 ft.\*lbf)**