








PROCEDURES NECESSARY WHEN ECU OR OTHER PARTS ARE REPLACED

Replacement Part	Necessary Procedure	Effect/Inoperative Function when Necessary Procedures are not Performed	Link
ECM	Register VIN	DTC P0630 is output	 (for 1GR-FE)  (for 1VD-FTV)
	Supply pump initialization (for 1VD-FTV)	Engine startability	 ()
Fuel injector(s) (for 1VD-FTV)	Injector compensation code(s) registration	DTC is output.	 ()
Fuel supply pump (for 1VD-FTV)	Supply pump initialization	Engine startability	 ()
<ul style="list-style-type: none"> Transponder key ECU assembly ECM Key 	Registration	Engine starting	Refer to the Service Bulletin for the registration procedure.
<ul style="list-style-type: none"> Door control transmitter Door control with receiver ECU assembly 	Register recognition code	Wireless door lock operation	 ()
Timing belt (for 1HZ)	Information mode reset operation	<ul style="list-style-type: none"> Does not illuminate when replacement is necessary Illuminates when replacement is not necessary 	 ()