

PROCEDURE**1.INSPECT ACCELERATOR PEDAL SENSOR ASSEMBLY****78110K**

- a. Connect the GTS to the DLC3.
- b. Turn the ignition switch to ON.
- c. Turn the GTS on.
- d. Enter the following menus: Powertrain / Engine and ECT / Data List / Accel Sensor Out No. 1 and Accel Sensor Out No. 2.

Powertrain > Engine > Data List

Tester Display
Accel Sensor Out No.1
Accel Sensor Out No.2

Execute

- e. Read the value displayed on the GTS.

Standard Voltage:

Accelerator Pedal Operation	Accel Sensor Out No. 1	Accel Sensor Out No. 2
Released	0.5 to 1.1 V	1.2 to 2.0 V
Depressed	2.6 to 4.5 V	3.4 to 4.75 V

If the result is not as specified, check the accelerator pedal sensor assembly, wire harness and ECM.