

PROCEDURE

1.INSTALL STABILIZER LINK SUB-ASSEMBLY

48802

- a. Install the 2 collars and 2 cushions to the rear stabilizer bar.
- b. Install the nut, bolt and stabilizer link sub-assembly to the rear stabilizer bar.

Torque:**25.5 N*m (260 kgf*cm, 19 ft.*lbf)****HINT:**

Use the same procedure described for the other side.

- c. Install a new nut, 3 rear stabilizer cushion retainers, rear stabilizer bar link bracket and 2 rear stabilizer cushions to the stabilizer link sub-assembly.

Torque:**14.7 N*m (150 kgf*cm, 11 ft.*lbf)****HINT:**

Use the same procedure described for the other side.


2.INSTALL REAR STABILIZER BUSHING

48815R

- a. Install the 2 rear stabilizer bushings to the rear stabilizer bar.

3.INSTALL REAR STABILIZER BAR

48812



Install the rear stabilizer bar and 2 rear stabilizer brackets to the rear axle housing with the 4 bolts.

Torque:**29.7 N*m (303 kgf*cm, 22 ft.*lbf)****NOTICE:**

Install the 2 rear stabilizer bushings to the outside of the paint line on the rear stabilizer bar.

4.CONNECT REAR STABILIZER BAR LINK BRACKET

48826B

- a. Connect the rear stabilizer bar link bracket with the 3 bolts.

Torque:**29.7 N*m (303 kgf*cm, 22 ft.*lbf)**

HINT:

Use the same procedure described for the other side.

**5.INSTALL REAR WHEEL**

[Click here](#)Suspension>TIRE / WHEEL>TIRE AND WHEEL>INSTALLATION

© 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.