


PROCEDURE

1.INSTALL BACK-UP LIGHT SWITCH ASSEMBLY

84210



Using SST, install a new gasket and the back-up light switch assembly to the transmission case.

SST


09817-16011 09961-01270

Torque:

Specified tightening torque : 44.1 N*m (450 kgf*cm, 33 ft.*lbf)

HINT:

- Calculate the torque wrench reading when changing the fulcrum length of the torque wrench.
Click here [General>INTRODUCTION>REPAIR INSTRUCTION>PRECAUTION](#)
- When using SST (fulcrum length of 200 mm (7.8740 in.)) + torque wrench (fulcrum length of 380 mm (14.9606 in.)): 28.9 N*m (295 kgf*cm, 21 ft.*lbf)



Connect the back-up light switch connector clamp to the bracket and connect the wire harness clamp as shown in illustration.

- c. Connect the back-up light switch connector.