

1GR-FE FUEL FUEL PRESSURE REGULATOR INSTALLATION

PROCEDURE



1.INSTALL FUEL PRESSURE REGULATOR ASSEMBLY

23280

- a. Apply a light coat of spindle oil or gasoline to a new O-ring and install the O-ring to the fuel pressure regulator assembly.
- b. Install the fuel pressure regulator assembly with the 2 bolts to the fuel delivery pipe sub-assembly.
Torque:
9.0 N*m (92 kgf*cm, 80 in.*lbf)
- c. Connect the vacuum hose to the fuel pressure regulator assembly.



2.CONNECT NO. 2 FUEL PIPE SUB-ASSEMBLY

23802B

[Click here](#)Engine / Hybrid System>1GR-FE FUEL>FUEL INJECTOR>INSTALLATION



3.CONNECT CABLE TO NEGATIVE BATTERY TERMINAL



4.INSPECT FOR FUEL LEAK

[Click here](#)Engine / Hybrid System>1GR-FE FUEL>FUEL INJECTOR>INSTALLATION