

PROCEDURE



1.INSTALL ENGINE OIL PRESSURE SWITCH ASSEMBLY

83530

- a. Apply adhesive to 2 or 3 threads of the engine oil pressure switch assembly.

Adhesive:

Toyota Genuine Adhesive 1344, Three Bond 1344 or equivalent

NOTICE:

Do not apply adhesive to the oil inlet port of the engine oil pressure switch assembly.

- b. Using a 24 mm deep socket wrench, install the engine oil pressure switch assembly.

Torque:

15 N*m (153 kgf*cm, 11 ft.*lbf)

NOTICE:

Do not start the engine within 1 hour of installation.

- c. Connect the engine oil pressure switch connector.



2.INSPECT FOR OIL LEAK

[Click here](#)Engine / Hybrid System>1GR-FE LUBRICATION>OIL AND OIL FILTER>REPLACEMENT



3.CHECK ENGINE OIL LEVEL

[Click here](#)Engine / Hybrid System>1GR-FE LUBRICATION>LUBRICATION SYSTEM>ON-VEHICLE INSPECTION