


WINCH REMOTE CONTROL SWITCH INSPECTION

PROCEDURE

1.INSPECT OVERHEAT TEMPERATURE INDICATOR



- a. Apply battery voltage and check operation of the remote control switch as shown in the table below.


OK:

Measurement Condition	Specified Condition
Battery positive (+) → Terminal B Battery negative (-) → Terminal E	Overheat temperature indicator light illuminates and buzzer sounds

If the result is not as specified, replace the remote control switch assembly.

2.INSPECT REMOTE CONTROL SWITCH CIRCUIT

38640



- a. Measure the resistance according to the value(s) in the table below.

Standard Resistance:

Tester Connection	Switch Condition	Specified Condition
A - B*1 B - C B - E*2	NEUTRAL	Below 1 Ω
B - D	IN	Below 1 Ω
B - F	OUT	Below 1 Ω

HINT:

- *1: Connect the positive (+) lead of the ohmmeter to terminal B and the negative (-) lead to terminal A.
- *2: Connect the positive (+) lead of the ohmmeter to terminal E and the negative (-) lead to terminal B.

If the result is not as specified, replace the remote control switch assembly.

© 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.