

CAUTION / NOTICE / HINT

HINT:

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.


PROCEDURE



1.INSTALL LOWER ARM BUSH

48654

a.



Using SST and a press, install a new lower arm bush.

SST**09710-22042 (09710-02061)****NOTICE:**

Install the lower arm bush in the direction shown in the illustration.



2.TEMPORARILY INSTALL FRONT LEADING ARM ASSEMBLY

48610A

- Temporarily install the front leading arm assembly to the front axle housing assembly with 2 new bolts, 2 washers and 2 nuts.
- Temporarily install the front leading arm assembly to the frame with a new bolt, washers and nut.




3.INSTALL FRONT WHEEL

4.STABILIZE SUSPENSION

[Click here](#)Suspension>FRONT SUSPENSION>FRONT COIL SPRING>INSTALLATION

5.TIGHTEN FRONT LEADING ARM ASSEMBLY

48610A



- a. Tighten the 2 bolts and 2 nuts.


Torque:

171.6 N*m (1750 kgf*cm, 127 ft.*lbf)

NOTICE:

Since a stopper nut is used, tighten the bolt.

- b.



Tighten the bolt and nut.

Torque:

176.5 N*m (1800 kgf*cm, 130 ft.*lbf)