

PROCEDURE

1. PRECAUTION

CAUTION:

Do not use the swing arm type lift and plate type lift.

Otherwise, the vehicle may fall since its center of gravity is toward the front of the vehicle.

[Click here](#)[General](#)>[INTRODUCTION](#)>[REPAIR INSTRUCTION](#)>[VEHICLE LIFT AND SUPPORT LOCATIONS](#)

2.REMOVE WHEEL ASSEMBLY

- a. Loosen the axle hub nuts approximately 90°.
- b. Jacking up the vehicle and remove the axle hub nuts and wheel assembly.