


WINCH RELAY INSPECTION

PROCEDURE


1.INSPECT WINCH MAIN RELAY



a. Push in the plunger and release it. Check that it returns quickly to its original position.

b.

*a



P

*a

Component without harness connected
(Winch Main Relay)

Measure the resistance according to the value(s) in the table below.

Standard Resistance:

Tester Connection	Condition	Specified Condition
A - B	(when battery voltage is not applied to terminals 1 and 2)	10 MΩ or higher

Tester Connection	Condition	Specified Condition
	(when battery voltage is applied to terminals 1 and 2)	Below 1 Ω
	(Plunger not pressed)	10 M Ω or higher
	(Plunger pressed)	Below 1 Ω

If the result is not as specified, replace the winch main relay.