


## CAUTION / NOTICE / HINT

**HINT:**

- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.

## PROCEDURE

**1.INSPECT REAR AXLE SHAFT LH****42312****a.**

Inspect the rear axle shaft runout.

**Maximum runout:**  
**0.8 mm (0.031 in.)**

**HINT:**

If the rear axle shaft or flange is damaged or worn, or if the runout is more than the maximum, replace the rear axle shaft.