

## PROCEDURE

### 1.DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL

### 2.REMOVE FRONT BUMPER COVER


52119A

[Click here](#)Vehicle Exterior>EXTERIOR PANELS / TRIM>FRONT BUMPER(for Step Type)>REMOVAL

### 3.REMOVE WINCH CONTROL WIRE


38649

a.



Remove the 2 nuts.

b.








Disconnect the connector.

c. Detach the clamp and remove the wire.

### 4.REMOVE FRONT BUMPER SIDE MOUNTING BRACKET ASSEMBLY


52130






	Bolt A
	Bolt B
	Nut
	Bolt C

- a. Remove the 2 bolts labeled A and 2 bolts labeled B.
- b. Remove the 2 nuts, 2 bolts labeled C and front bumper side mounting bracket assembly.

a.




*1	Cable
*2	Wire
	Bolt
	Connector
	Nut

Remove the 2 bolts and cable.

b. Disconnect the connector.

c. Remove the nut and disconnect the wire.

d.



Using a crane or equivalent, remove the winch assembly from the vehicle.

**CAUTION:**

Be careful as the winch assembly is very heavy.

**NOTICE:**

- Be sure to perform the operation with 2 persons or more.
- Be careful not to damage the winch assembly.

