

## PROCEDURE

### 1.REMOVE VALVE LIFTER

13751

- a. Remove the valve lifter.


**HINT:**

Arrange the removed parts so that they can be reinstalled in their original locations.

### 2.REMOVE VALVE

**HINT:**

Arrange the removed parts so that they can be reinstalled in their original locations.



Using SST, compress the inner compression spring and remove the valve spring retainer lock.


**SST**

**09202-70020 (09202-00010)**

- b. Remove the valve, inner compression spring and valve spring retainer.

### 3.REMOVE VALVE SPRING SEAT

13734



Using compressed air and a magnet hand, remove the valve spring seat by blowing air.