

## PROCEDURE

### 1.INSPECT FUEL PUMP RESISTOR

28380A

- a. Measure the resistance according to the value(s) in the table below.

**Standard Resistance:**

Tester Connection	Condition	Specified Condition
1 - 2	20°C (68°F)	0.71 to 0.75 $\Omega$

If the result is not as specified, replace the fuel pump resistor.