


CAUTION / NOTICE / HINT**NOTICE:**

- When using a vise, place aluminum plates between the part and vise.
- When using a vise, do not overtighten it.

PROCEDURE**1.INSPECT TIE ROD END SUB-ASSEMBLY LH****45047**

- Secure the tie rod end sub-assembly LH in a vise.
- Install the castle nut to the stud bolt.
- Flip the ball joint back and forth 5 times or more.
- Using a torque wrench, turn the nut continuously at a rate of 2 to 4 seconds per turn and take the torque reading on the 5th turn.

Standard turning torque:**0.7 to 2.7 N*m (8 to 27 kgf*cm, 7 to 23 in.*lbf)**

If the turning torque is not within the specified range, replace the tie rod end sub-assembly LH.

2.INSPECT TIE ROD END SUB-ASSEMBLY RH**45046****HINT:**

Use the same procedures described for the LH side.