



ILLUSTRATION



*1	CYLINDER BOOT	*2	DUST BOOT PROTECTOR LH
*3	PARKING BRAKE SHOE ADJUSTING HOLE PLUG	*4	PISTON SEAL
*5	REAR DISC	*6	REAR DISC BRAKE ANTI-SQUEAL SHIM
*7	REAR DISC BRAKE BLEEDER PLUG	*8	REAR DISC BRAKE BLEEDER PLUG CAP
*9	REAR DISC BRAKE BUSH DUST BOOT	*10	REAR DISC BRAKE CYLINDER ASSEMBLY LH
*11	REAR DISC BRAKE CYLINDER HOLE PLUG	*12	REAR DISC BRAKE CYLINDER MOUNTING LH
*13	REAR DISC BRAKE CYLINDER SLIDE BUSH	*14	REAR DISC BRAKE PAD
*15	REAR DISC BRAKE PAD WEAR INDICATOR PLATE	*16	REAR DISC BRAKE PISTON
*17	REAR FLEXIBLE HOSE LH	*18	REAR NO. 1 DISC BRAKE PAD SUPPORT PLATE
*19	REAR NO. 2 DISC BRAKE PAD SUPPORT PLATE	*20	CYLINDER SLIDE PIN
*21	GASKET	*22	UNION BOLT
*23	PLATE WASHER	-	-

	N*m (kgf*cm, ft.*lbf): Specified torque	•	Non-reusable part
	Lithium soap base glycol grease	-	-