

# Altair® HyperWorks®

2022.2

## Define Representations

Create your own user defined representation. User defined representations are saved to the settings and will be available in subsequent HyperMesh sessions.

1. In the Part Browser, right-click on part assemblies or parts and select **Representations** > (and then) **Settings** > (and then) **User Representations** from the context menu.
2. In the **User Representation** dialog, click + to add a new representation.
3. In the Representation field, enter a name for the representation.
4. In the Param File and Criteria File fields, select the appropriate mesh parameter and criteria file.
5. If the representation is for solids, select the **Solid** checkbox.
6. Click **OK**.