

Altair® HyperWorks®

2022.2

Sync Metadata To PDM

Sync PDM metadata (PDM PID, PDM Thickness, PDM Material, and PDM MID) based on a selected part or part's metadata (PID, Thickness, Material, MID).

In the Part Browser, right-click on a part or parts and select **Representations** > (and then) **Sync Metadata** from the context menu.

*When a part has multiple properties, only the first property will display in the PID PDM field when you select **Sync Metadata**.

When Material is not mentioned in PDM metadata, material is created by default with MID.