

# Altair® HyperWorks®

2022.2

## Transform Parts Assemblies and Parts

Translate, rotate, reflect, scale, and position selected parts and part assemblies.

1. In the Part Browser, right-click on a part or a part assembly and select **Transform** from the context menu.
2. In the Action field, select an action to perform on your selection.
3. Define any relevant parameters and then click **Apply**.