

Altair® HyperWorks®

2022.2

Reload Representations

Restore part representations to their original state.

In the Part Browser, right-click on parts or part assemblies and select **Representation** > (and then) **Reload** from the context menu.

Representations are reloaded from the repository.