

# Altair® HyperWorks®

2022.2

## Organize Part Assemblies and Parts

Organize part assemblies, parts, and components in your model.

Entity organization rules are as follows:

- The Model is the root of the hierarchy in the browser. It represents the contents of the HyperMesh binary file and can contain part assemblies, parts, and components.
- A part assembly can contain part assemblies and parts.
- A part can only contain components.
- Reorganize part assemblies, parts, and components in the Part Browser.
  1. From the Part Browser, left-click on an entity and drag and drop it to a new location.

In Figure 1, Component B is being reorganized into Part B.




Figure 1.

- Reorganize parts and components using the Organize tool.
  1. From the Assembly ribbon, click the **Organize** tool.



Figure 2.

2. Use the first selector on the guide bar to pick the parts or components to move.
3. Use the second selector to pick a destination collector.
4. Click ► to save your changes and remain in the tool or click ✓ to save your changes and exit the tool.

- Reorganize components into a new part using the Organize panel.
  1. From the Tool page, click the **Organize** panel, **Parts** subpanel.
  2. Use the comps selector to select the component(s) to move.
  3. In the dest part field, select the part to move the selected components into.
  4. Click **move**.