


9.3.1 Main control board of hydraulic module



Order	Port	Code	Assembly unit	Order	Port	Code	Assembly unit
1	CN21	POWER	Port for power supply	19	CN36	M1 M2 T1 T2	Port for remote switch Port for thermostat transfer board
2	S3	/	Rotary dip switch	20	CN19	P Q	Communicate port between indoor unit and outdoor unit
3	DIS1	/	Digital display	21	CN14	A B X Y E	Port for communication with the wired controller
4	CN5	GND	Port for ground			1 2 3 4 5	Port for communication with the wired controller
5	CN28	PUMP	Port for variable speed pump power input	22	CN30	6 7	Communicate port between indoor unit and outdoor unit
6	CN25	DEBUG	Port for IC programming			9 10	Port for Internal machine Cascade
7	S1,S2,S4,SW9	/	Dip switch			26 30/31 32	Compressor run/Defrost run
8	CN4	USB	Port for USB programming	23	CN7	25 29	Port for antifreeze E-heating tape(external)
9	CN8	FS	Port for flow switch			27 28	Port for additional heat source
10	CN6	T2 T2B TW_in TW_out T1	Port for temperature sensors of refrigerant liquid side temperature of indoor unit (heating mode) Port for temperature sensors of refrigerant gas side temperature of indoor unit (cooling mode) Port for temperature sensors of inlet water temperature of plate heat exchanger Port for temperature sensors of outlet water temperature of plate heat exchanger Port for temperature sensors of final outlet water temperature of indoor unit	24	CN11	1 2	Input port for solar energy
11	CN24	Tbt1	Port for upper temperature sensor of balance tank			3 4 15	Port for room thermostat
12	CN16	Tbt2	Reserved			5 6 16	Port for SV1(3-way valve)
13	CN13	T5	Port for domestic hot water tank temp. sensor			7 8 17	Port for SV2(3-way valve)
14	CN15	Tw2	Port for outlet water for zone 2 temp. sensor			9 21	Port for zone 2 pump
15	CN18	Tsolar	Port for solar panel temp sensor			10 22	Port for outside circulation pump
16	CN17	PUMP_BP	Port for variable speed pump communication			11 23	Port for solar energy pump
17	CN31	HT COM CL SG	Control port for room thermostat (heating mode) Power port for room thermostat Control port for room thermostat (cooling mode) Port for smart grid (grid signal)			12 24	Port for DHW pipe pump
18	CN35	EVU	Port for smart grid (photovoltaic signal)			13 16	Control port for tank booster heater
				25	CN2	TBH_FB	Feedback port for external temperature switch(shorted in default)
				26	CN1	IBH1/2_FB	Feedback port for temperature switch (shorted in default)
						IBH1	Control port for internal backup heater 1
				27	CN22	IBH2	Reserved
						TBH	Control port for tank booster heater
				28	CN41	HEAT8	Port for anti-freeze electric heating tape(internal)
				29	CN40	HEAT7	Port for anti-freeze electric heating tape(internal)
				30	CN42	HEAT6	Port for anti-freeze electric heating tape(internal)
				31	CN29	HEAT5	Port for anti-freeze electric heating tape(internal)
				32	CN32	IBH0	Port for backup heater