

Weather temp. settings

Weather temp. settings introduction

>

Zone 1 heating mode

ON >

Zone 1 cooling mode

OFF >

Zone 2 heating mode

OFF >

Weather temp. settings

Zone 2 cooling mode

OFF >

The status indicator on the right of the interface shows “ON” when the setting is active, and “OFF” when the setting is inactive.

NOTE

- If the temperature is controlled by water temperature, you cannot adjust the set temperature (in home page) manually once this function is enabled.