













		Set temperature		When Zone 2 is selected, the zone indicator and set temperature are visible.
3*	Zone 2 appliances	Radiator		Displays  ,  or  depending on the installer setting. The icon color is orange when Zone 2 is in heating mode. The icon color is blue when Zone 2 is in cooling mode. The icon color is gray when Zone 2 is OFF.
		Underfloor heating		
		Fan coil unit		
4	Zone 1 temperatures	Temperature	29°C 29°C	The indicator lights up when Zone 1 is ON and turns gray when Zone 1 is OFF. When the temperature is controlled by room temperature,  is displayed. When the temperature is controlled by water temperature,  is displayed. When Zone 1 is selected, the zone indicator and set temperature are visible.
		Current room temperature		
		Current water temperature		
		Set temperature		
5	Zone 1 indicator		Zone 1	Indicates this zone is Zone 1.