

Time	The time when the unit starts to execute the following command.
Mode	The mode in which the unit starts to run from the set time. OFF means Zone 1 turns off at the set time.
Temp	The target temperature of the unit in the set mode.
Status	The status of the schedule setting. If no timer is active, Zone 1 daily timer is inactive.

Zone 2 daily timer

Daily schedule for Zone 2. Refer to Zone 1 daily timer.
This item is invisible if DOUBLE ZONE is disabled.

DHW daily timer

Daily schedule for DHW heating. Refer to Zone 1 daily timer.
This item is invisible if DHW MODE is disabled.

Zone 1 weekly schedule

Weekly schedule for Zone 1. Up to 4 schedules can be set.

Zone 1 weekly schedule

Schedule 1
ON >

Schedule 2
ON >

Schedule 3
OFF >

Schedule 4
ON >
