

ECO**	
Temperature level*	Up to 8 curves preset by manufacturer, from which you can choose one.
ECO timer*	<p>ECO timer: Indicates the status of ECO timer.</p> <p>-If the ECO timer is inactive, the unit will operate in ECO mode all the way.</p> <p>-If the ECO timer is active, the unit will operate in ECO mode only during the set time period.</p> <p>Start: the hour from which the ECO curve is enabled; End: the hour from which the ECO curve is disabled</p> <p>-If the set Start time is later than the set End time, the unit will operate in ECO mode throughout a day. The Start time and End time cannot be set to the same value. Otherwise, the most recent setting is invalid, and a notice window appears.</p>
Custom	
Temperature setting*	The parameters of the curve can be adjusted.
Temperature offset*	<p>Fine tune the curve.</p> <p>-Slightly increase or decrease the temperature of the curve.</p>

\* Invisible if Temperature curve function is inactive.