

** Available only for Zone 1 heating mode and single zone application.

Zone 1 cooling mode

Cooling temperature curve setting for Zone 1.
Refer to Zone 1 heating mode.

Zone 2 heating mode

Heating temperature curve setting for Zone 2.
Refer to Zone 1 heating mode.

NOTE

Invisible if DOUBLE ZONE is disabled.

Zone 2 cooling mode

Cooling temperature curve setting for Zone 2.
Refer to Zone 2 heating mode.

NOTE

Invisible if DOUBLE ZONE is disabled.

Introduction to weather temp. settings

It provides some basic knowledge about the temperature curve.
For more information, see FAQ.