



Mono


9.4 Wired Controller Setting

Go to "MENU"> "WLAN SETTING"> "AP MODE". Press "OK" to activate the WLAN, refer to Figure 3-8.1. Select **YES**, press **OK** to select AP mode. Select **AP Mode** correspondingly on the mobile device and continue the follow-up settings according to the APP prompts. During the Wireless distribution process, the LCD icon “” flashes to indicate that the network is being deployed. After the process is completed, the icon “” will be constantly on.

MENU	2/2
SERVICE INFORMATION	
OPERATION PARAMETER	
FOR SERVICEMAN	
WLAN SETTING	
SN VIEW	
OK ENTER	↕

WLAN SETTING
APP MODE
RESTORE WLAN SETTING
OK ENTER
↕

AP MODE
Do you want to activate the WLAN network and exit?
NO YES
OK CONFIRM
↕

01-01-2018	23:59	13	
08:00	ON	38 °C	
23 °C			
E01			

This icon will flash

9.4.1 Connect to new Wi-Fi

Cancel



Please keep the device as close as possible to the WiFi router

Network preparation ○
Device networking
Account binding

Once the connection starts, the app will ask you to connect your phone with another Wi-Fi Midea_c3_xxxx

Connect device



- ① The home appliance has sent out wi-fi signal, please connect your mobile phone to this wi-fi

WiFi: midea_c3_xxxx

WiFi password: 12345678

- ② After successful connection MSmartLife to start the connection

Click here and connect your phone with the new Wi-Fi

Connect your appliance to WiFi