

Part 3

Installation and Field Settings

1	Preface to Part 3.....	58
2	Installation	59
3	Water Pipework	64
4	Electrical Wiring	68
5	DIP Switch Settings.....	72
6	Internal Circulation Pump.....	72
7	User Interface Field Settings	73
8	Operation parameter.....	92
9	Network Configuration Guidelines	93
10	USB function guidelines.....	98
11	Climate Related Curves.....	100
12	Error Code Table	103