


### Zone 1 heating mode

Temperature curve	
Temperature curve type	Standard
Temperature level	4
Temperature offset	0°C

Temperature curve	Indicates the status of temperature curve function.
Temperature curve type*	<p>Select which curve type you want to apply. Three types in all: Standard, ECO, Custom Standard: Curves preset by manufacturer, mainly for common conditions ECO: Curves preset by manufacturer, for energy saving Custom: The parameters of the curve can be adjusted, <b>mainly for advanced users</b>.</p>
Standard	
Temperature level*	Up to 8 curves preset by manufacturer, from which you can choose one.
Temperature offset*	<p>Fine tune the curve. -Slightly increase or decrease the temperature of the curve.</p>