



- All pins of ports P1 and P2 can be used as an interrupt source.
- Capacitive sensing is enabled by setting PxSEL=0 and PxSEL2=1.