



Synchronization of

WIDEPIX devices

Version 1.0

User Guide

GENERAL DESCRIPTION	3
INTRODUCTION.....	3
PHYSICAL INTERCONNECTION	3
I/O CONNECTOR DESCRIPTION	3
SOFTWARE.....	5
STEP-BY-STEP PROCEDURES.....	6
TRIGGERING OF ONE FITPIX DEVICE WITH EXTERNAL SOURCE (WITHOUT FEEDBACK)	6
TWO FITPIX DEVICES WORKING IN SYNCHRONIZATION	8
PERFORMANCE	10
COPYRIGHT	12

General description

Introduction

WIDEPIX® devices in general (**FITPIX**, **MODUPIX**, **WIDEPIX_{2x5}**) allow:

1. mutual time synchronization of two or more devices
2. external triggering of one or more devices

To achieve synchronization or triggering, one device must be defined as **Master**, and others are **Slaves**.

In this document, **FITPIX** is used as an example on all photographs.

Physical interconnection

When connecting several **WIDEPIX®** devices to computer only using USB cable, the precise timing (<1us) is not possible due to frame granularity of USB communication (1ms). For this purpose ADVACAM s.r.o. delivers **synchronization cable** (with labeled Master end) allowing direct



interconnection among devices. *Synchronization cable* is then connected to **I/O connector**.

I/O connector description

The I/O digital connector contains four signals (pins 4,6,8,10) that are used for mutual synchronization.


1	GND	2	+5V
3	Reserved	4	Ready In
5	Reserved	6	Trigger In
7	Reserved	8	Ready Out
9	Reserved	10	Trigger Out

Logic level voltages for input signals

I/O Conn. Input CMOS (pin 4,6)		Min	Max	
VINL	Voltage Low	0	1.15	V
VINH	Voltage High	2.15	5.0	V

Software


Synchronization is only working with **PiXET PRO** software.




Step-by-step procedures

Triggeing of one **WIDEPIX®** devices with external source (without feedback)

1. Connect external triggering signal to **Trigger In** pin (6).
2. Start **PIXET PRO** software
3. Open **More Measurement Settings**, and select trigger settings to **Started by HW Trigger**.




4. Open Select **More Detector Settings** window and under tab **Readout**.




5. Depending on the **TriggerStg** value, the behavior of shutter signal is following.


TriggerStg = 0




TriggerStg = 1



TriggerStg = 2



TriggerStg = 3



Two FitPIX devices working in synchronization

1. Connect both **WIDEPIX®** devices to USB
2. Connect **synchronization cable** to **I/O connector** of both **WIDEPIX®** devices (observe which one is Master/Slave)



3. Start **PIXET PRO** software
4. Open **More Detector Settings** window and under tab Readout

Property	Value	Description
Firmware	Firmware 1.2 TSA (23.04.2015)	Firmware version
TriggerMaster	<input checked="" type="checkbox"/> Yes	Master device
TriggerOutLevel	0	Trigger out active level (0=log 0, 1 = log 1)
TriggerStg	0	Settings of trigger (0=log 0, 1 = log 1, 2 - rising edge, 3 - falling edge)
TriggerWaitForReady	<input checked="" type="checkbox"/> Yes	Wait for trigger ready

☐ Refresh

OK Cancel

If the selected **WIDEPIX®** device is Master, then check **TriggerMaster** to set Yes,


Property	Value	Description
Firmware	Firmware 1.2 TSA (23.04.2015)	Firmware version
TriggerMaster	<input type="checkbox"/> No	Master device
TriggerOutLevel	0	Trigger out active level (0=log 0, 1 = log 1)
TriggerStg	0	Settings of trigger (0=log 0, 1 = log 1, 2 - rising edge, 3 - falling edge)
TriggerWaitForReady	<input checked="" type="checkbox"/> Yes	Wait for trigger ready

☐ Refresh

OK Cancel

otherwise leave unchecked to set No.


5. Open **More Measurement Settings**, and select trigger settings to **Started by HW Trigger**.




6. Now press **Start** button on both **WIDEPIX[®]** devices (in any order) to start synchronized measurement.

Performance


- Two **WIDEPIX**[®] devices with different Time of measurement
- (20ms for Master and 10ms for Slave)



- Shutter delay from Master to Slave device ($140\text{ns} \pm 10\text{ns}$).



- Delay from **Trigger In** to **Shutter** ($140\text{ns} \pm 10\text{ns}$).



Copyright

ADVACAM s.r.o.

Na Balkane 2075/70, CZ 130 04 Praha 3
Czech Republic

Tel: +420-603-444112, 589854;

Email: info@advacam.cz

www.advacam.cz