


# **USER MANUAL**


# TABLE OF CONTENTS

1. <u>How to navigate the Menu</u>	2
a. Importing and Exporting.....	2
2. <u>Viewing of Data/Values</u>	3
a. Declared Distances.....	3
b. Calculation Breakdown.....	3
3. <u>Runway</u>	3
a. Selecting Runway.....	3
4. <u>Obstacle</u>	4
a. Adding new Obstacle.....	4
5. <u>Main Visualization</u>	4
a. Side View.....	4
b. Top Down View.....	4

1. How to navigate the Menu
  - a. Importing and Exporting:
    - i. Login as Airport Manager.
    - ii. Direct your view to the top left of the page.



- iii. Click on the "File" button.



- iv. Now you can either select import/export depending on what you wish to do.

## 2. Viewing of Data/Values

### a. Declared Distances:

- i. Direct your view to the top left pane of the page titled “Declared Distances”.
- ii. Here you can see the values of the “Original Distances” as well as the “Recalculated Distances” for both the take off away and take off towards.
- iii. You can sort the values in order of descending/ascending simply by interacting with the small triangle next to the title of the table.


### b. Calculation Breakdown:

- i. Direct your view to the bottom left pane of the page titled “Calculation Breakdown”.
- ii. Here you can view the calculations and the formulas used to calculate the final values.
- iii. You can also switch between tabs of TORA, TODA, LDA, and ASDA simply by interacting/clicking on the menu above where the calculations are shown.

## 3. Runway

### a. Selecting Runway:

- i. Navigate yourself to the top left pane of the page labelled “Runway”.
- ii. Here you can select the desired runway simply by selecting from a list in a drop down box.



- iii. Then you can view all the fixed data below the drop down box.
- iv. Here you can view the **DATA**.
- v. You are also able to sort the values in order of ascending/descending simply by interacting with the triangle next to the titles on the table itself.

#### 4. Obstacle

##### a. Viewing obstacle data/values:

- i. Direct yourself to the bottom right pane of the page.
- ii. Here you can view values such as the obstacle name, height, width, length as well as the distances.

#### 5. Main Visualization

##### a. Side View:

- i. Navigate yourself to the top of the middle pane on the page.



- ii. Select "Side View".
- iii. Here you are able to see the selected runway as well as the direction it is facing from a side view.
- iv. You can also change the view by clicking the "View Right" button at the bottom of the pane.

##### b. Top Down View:

- i. Navigate yourself to the top of the middle pane on the page.



- ii. Select "Top View".
- iii. Now you are able to see the selected runway as well as the direction it is facing from a top down view.
- iv. You can also change the view by clicking the "View Right" button at the bottom of the pane.