



# **Cluster Expansion**

## **System Manager Classic**

NetApp  
December 09, 2021

This PDF was generated from [https://docs.netapp.com/us-en/ontap-sm-classic/online-help-96-97/task\\_adding\\_nodes\\_to\\_cluster\\_using\\_system\\_manager.html](https://docs.netapp.com/us-en/ontap-sm-classic/online-help-96-97/task_adding_nodes_to_cluster_using_system_manager.html) on December 09, 2021. Always check docs.netapp.com for the latest.

# Table of Contents

- Cluster Expansion ..... 1
  - Add nodes to a cluster ..... 1
  - Configure the network details of the nodes ..... 2

# Cluster Expansion

You can use System Manager to increase the size and capabilities of your storage by adding compatible nodes to the cluster and configuring the node network details. You can also view the summary of the nodes.

When you log in to System Manager, System Manager automatically detects compatible nodes that have been cabled but have not been added to the cluster and prompts you to add the nodes. You can add compatible nodes as and when System Manager detects the nodes or you can manually add the nodes at a later time.

## Add nodes to a cluster

You can use System Manager to increase the size and capabilities of your storage system by adding nodes to an existing cluster.

### Before you begin

- New compatible nodes must be cabled to the cluster.

Only the ports that are in the default broadcast domain will be listed in the Network window.

- All of the nodes in the cluster must be up and running.
- All of the nodes must be of the same version.

### Steps

1. Add the new compatible nodes to the cluster:

If you are...	Do this...
Not logged in to System Manager	<div><div><div>a. Log in to System Manager.</div><div><div><div><div>i</div></div></div><div><div>The new compatible nodes are automatically detected by System Manager at login. System Manager prompts you to add the new compatible nodes to the cluster.</div></div></div></div><div><div>b. Click <b>Add Nodes to Cluster</b>.</div><div>c. Modify the name of the nodes.</div><div>d. Specify the node licenses.</div><div>e. Click <b>Submit and Proceed</b>.</div></div></div>

If you are...	Do this...
Logged in to System Manager	<p>a. Click <b>Configuration &gt; Cluster &gt; Expansion</b>.</p> <p>System Manager searches for newly added nodes. If any warnings are displayed, you must fix them before proceeding. If new compatible nodes are discovered, proceed to the next step.</p> <p>b. Modify the name of the nodes.</p> <p>c. Specify the node licenses.</p> <p>d. Click <b>Submit and Proceed</b>.</p>

## Configure the network details of the nodes

You can use System Manager to configure the node management LIF and Service Processor settings for the newly added nodes.

### Before you begin

- Sufficient number of ports must be present in the default IPspace for LIF creation.
- All the ports must be up and running.

### Steps

1. Configure node management:
  - a. Enter the IP address in the **IP Address** field.
  - b. Select the port for node management in the **Port** field.
  - c. Enter the netmask and gateway details.
2. Configure Service Processor settings:
  - a. Select the **Override defaults** check box to override the default values.
  - b. Enter the IP address, netmask, and gateway details.
3. Click **Submit and Proceed** to complete the network configuration of the nodes.
4. Verify the details of the nodes in the **Summary** page.

## What to do next

- If your cluster is protected, you should create the required number of intercluster LIFs in the newly added nodes to avoid partial peering and unhealthy protection.
- If SAN data protocols are enabled in your cluster, you should create the required number of SAN Data LIFs for serving data.

### Related information

[Creating network interfaces](#)

## Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

## Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.