

NAME: Workind Solution, 2005 Sample

(B) ① 99% of the time that this error occurs is as a result of the user leaving a non-bootable disk in a bootable drive. Commonly, the floppy disk drive is ^{considered} left as bootable by the system - this can enable the computer to be started even if the harddrive fails. However, if a floppy disk has been left in the drive because it was used for any other reason, starting generates this error. Solution: Remove non-bootable disk.

A similar error can be caused by other disk types.

② READ THE DOCUMENTATION! Both software & hardware are required. The documentation gives the sequence. Often the sequence is most important.

③ If the busener is IDE (most probably) and it is on a drive cable with an existing drive, the master/slave settings (jumpers) can not be wrong. You cannot have 2 masters or 2 slaves. Check & correct.

④ Network card per pc with properly ^{wired} ~~wiring~~ ends. Network card per PC & 1 Hub.

In the event of errors - if software has been correctly installed - most problems are caused by connections. Check these and any indicator lights on network cards and the hub. Re-do wiring if necessary.