

#### 3.3.5.1 Line Weight Mapping of DWG import

When the DWG Line Weights are set to "Default" in the AutoCAD layer settings, the Line Weights in Revit will be assigned automatically according to a color layer mapping definition.

When the DWG Line Weights are set to a specified thickness in the AutoCAD layer settings, the Line Weights in Revit will be imported according to that thickness and the layer map text file will be ignored.