

# How to Install Vivado on Linux

Innova Lee(이상훈)  
gcccompil3r@gmail.com



https://www.xilinx.com



1

All ▾



Applications

Products

Developer Zone

Support

About

먼저 Xilinx 사이트에서 필요한 것들을 모두 다운 받도록 한다.



XILINX  
VERSAL™

Industry's First ACAP

Adaptive Compute Acceleration Platform

LEARN MORE



Support -> Downloads & Licensing

Applications

Products

Developer Zone

Support

About

## Support

Knowledge Base  
Documentation  
Community Forums  
Service Portal  
Design Hubs

## Services

Training  
**Downloads & Licensing**  
Product Return  
University Program  
Partner Design Services



Download Now



Documentation Navigator  
Download Today



Community Forums  
Join Now

New to Xilinx? Let us help guide you.

Learn More



Searching for Design Tools?  
Get Started



Xilinx Developer  
Forum

Learn More

Adaptive Compute Acceleration Platform

LEARN MORE

# Downloads

Vivado Installation Overview Video

Licensing Help

Alveo Acceleration Card Downloads

Vivado	Embedded Development	SDSoC Development Environment	SDAccel Development Environment	ISE	Device Models	CAE Vendor Libraries
--------	----------------------	-------------------------------	---------------------------------	-----	---------------	----------------------

## Version

- 2018.2
- 2018.1
- 2017.4
- Archive

### Vivado Design Suite - HLx Editions: Update 2 - 2018.2

#### Important

Vivado Design Suite 2018.2.2 is now available with support for

#### Production Devices

- Defense-Grade Zynq UltraScale+ MPSoC (-1M) Devices
  - XQZU7EV, XQZU15EG, XQZU19EG

For customers using these devices, Xilinx recommends installing Vivado 2018.2.2. For other devices, please continue to use Vivado 2018.2.

Note: Download verification is only supported with Google Chrome and

Download Includes	Vivado Design Suite HLx Editions (All Editions)
Last Updated	Oct 3, 2018
Answers	<a href="#">2018.2.2 - Vivado Known Issues</a>
Enablement	<a href="#">Installation and Licensing</a>



Applications

Products

Developer Zone

Support

About



Vivado Installation Overview Video

Licensing Help

Alveo Acceleration Card Downloads



Vivado

Embedded  
Development

SDSoC  
Development  
Environment

SDAccel  
Development  
Environment

ISE

Device Models

CAE Vendor  
Libraries

## Version

[2018.2](#)

[2018.1](#)

**2017.4**

[Archive](#)

### Vivado General Information - 2017.4

#### Important Information

Vivado 2017.3 and later versions require upgrading your license server tools to the Flex 11.14.1 versions listed below. Please note that Vivado 2017.3 is the last release that will support Solaris operating system. Xilinx will continue to support Window and Linux operating systems.

### Vivado Design Suite - HLx Editions: Update 1 - 2017.4

#### Important Information

Vivado Design Suite 2017.4 Update 1 is now available with support for  
**Production Devices**

Download Includes

Vivado Design Suite HLx  
Editions (All Editions)

Last Updated

Feb 8, 2018

Answers


[2017.4.1 - Vivado Known  
Issues and Release](#)

## Vivado Design Suite - HLx Editions - 2017.4 Full Product Installation


### Important

We strongly recommend to use the web installers as it reduces download time and saves significant disk space.

Please see [Installer Information](#) for details.

 [Vivado HLx 2017.4: WebPACK and Editions - Windows Self Extracting Web Installer](#) (EXE - 51.3 MB)

MD5 SUM Value : 39677d35779915411487e5d89fe27ee8

 [Vivado HLx 2017.4: WebPACK and Editions - Linux Self Extracting Web Installer](#) (BIN - 100.7 MB)

MD5 SUM Value : 915928e0f33af22f1370acc6ac32c2b5

Vivado HLx 2017.4: All OS  
installer Single-File Download

 [Vivado HLx 2017.4: All OS Installer Single-File Download](#) (TAR/GZIP - 16.17 GB)

MD5 SUM Value : 5a1bb63f893f0039e34c9f412dd063a9

Download Includes

Vivado Design Suite HLx Editions (All Editions)

Download Type

Full Product Installation

Last Updated

Dec 20, 2017

Answers

[2017.x - Vivado Known Issues](#)

Documentation

[2017.4 - Release Notes](#)

Enablement

[License Solution Center](#)

---

Xilinx - Adaptable. Intelligent. > [Sign In](#)

**Sign In**

Username \*

Password \*

Forgot your [username](#) or [password](#)?

**Sign In**

New to Xilinx? [Create your account](#)

By signing In, you agree to the Xilinx [Terms of Use](#) and [Privacy Policy](#).

City \*

Seoul

Country \*

Korea, Republic of

Phone

+82 [REDACTED]

Job Function \*

Professor/Instructor

Primary Market \*

Wireless Communications

State \*

2-letter code for your [US state](#) or [Canadian province](#).

Opening Xilinx\_Vivado\_SDK\_2017.4\_1216\_1.tar.gz

You have chosen to open:

Xilinx\_Vivado\_SDK\_2017.4\_1216\_1.tar.gz

which is: Gzip archive (16.2 GB)  
from: <https://xilinx-ax-dl.entitlenow.com>

What should Firefox do with this file?

☐ Open with

Archive Manager (default) ▾

☒ Save File

☐ Do this automatically for files like this from now on.

Cancel

OK

For more information about how we process your personal information, please see our [privacy policy](#).

Next



```
sdr@sdr-Samsung-DeskTop-System:~/install_vivado$ mv ~/Downloads/Xilinx_Vivado_SDK_2017.4_1216_1.tar.gz ./
sdr@sdr-Samsung-DeskTop-System:~/install_vivado$ tar zxvf Xilinx_Vivado_SDK_2017.4_1216_1.tar.gz
Xilinx_Vivado_SDK_2017.4_1216_1/
Xilinx_Vivado_SDK_2017.4_1216_1/lib/
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-crt-heap-l1-1-0.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-crt-time-l1-1-0.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-core-timezone-l1-1-0.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-core-sysinfo-l1-1-0.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/libboost_program_options.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-crt-locale-l1-1-0.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/libboost_xilinx.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-core-processthreads-l1-1-0.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/libInst_7z.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-core-rtlsupport-l1-1-0.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-core-interlocked-l1-1-0.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-core-string-l1-1-0.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-crt-stdio-l1-1-0.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/libboost_graph.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/libboost_date_time.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/msvcr110.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/libboost_regex.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/libInst_Client7z.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/libboost_context.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/libboost_signals.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-core-synch-l1-2-0.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-crt-filesystem-l1-1-0.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/libboost_math_c99.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-core-synch-l1-1-0.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-crt-private-l1-1-0.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/libboost_log.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-core-processthreads-l1-1-1.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/msvcpl140.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-crt-string-l1-1-0.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-core-handle-l1-1-0.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-core-heap-l1-1-0.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/concrt140.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/libboost_chrono.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-core-localization-l1-2-0.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-core-namedpipe-l1-1-0.dll
Xilinx_Vivado_SDK_2017.4_1216_1/lib/win64.o/api-ms-win-core-datetime-l1-1-0.dll
```

```
Terminal File Edit View Search Terminal Help
sdr@sdr-Samsung-DeskTop-System:~/install_vivado$ ls
Xilinx_Vivado_SDK_2017.4_1216_1  Xilinx_Vivado_SDK_2017.4_1216_1.tar.gz
sdr@sdr-Samsung-DeskTop-System:~/install_vivado$ mv ~/Downloads/petalinux-v2017.4-final-installer.run ./
sdr@sdr-Samsung-DeskTop-System:~/install_vivado$ ls
petalinux-v2017.4-final-installer.run  Xilinx_Vivado_SDK_2017.4_1216_1.tar.gz
Xilinx_Vivado_SDK_2017.4_1216_1
sdr@sdr-Samsung-DeskTop-System:~/install_vivado$
```

```
Terminal File Edit View Search Terminal Help
sdr@sdr-Samsung-DeskTop-System:~/install_vivado/Xilinx_Vivado_SDK_2017.4_1216_1$ ls
api-ms-win-core-console-l1-1-0.dll      api-ms-win-crt-environment-l1-1-0.dll
api-ms-win-core-datetime-l1-1-0.dll      api-ms-win-crt-file-system-l1-1-0.dll
api-ms-win-core-debug-l1-1-0.dll          api-ms-win-crt-heap-l1-1-0.dll
api-ms-win-core-errorhandling-l1-1-0.dll  api-ms-win-crt-locale-l1-1-0.dll
api-ms-win-core-file-l1-1-0.dll           api-ms-win-crt-math-l1-1-0.dll
api-ms-win-core-file-l1-2-0.dll           api-ms-win-crt-multibyte-l1-1-0.dll
api-ms-win-core-file-l2-1-0.dll           api-ms-win-crt-private-l1-1-0.dll
api-ms-win-core-handle-l1-1-0.dll         api-ms-win-crt-process-l1-1-0.dll
api-ms-win-core-heap-l1-1-0.dll           api-ms-win-crt-runtime-l1-1-0.dll
api-ms-win-core-interlocked-l1-1-0.dll    api-ms-win-crt-stdio-l1-1-0.dll
api-ms-win-core-libraryloader-l1-1-0.dll  api-ms-win-crt-string-l1-1-0.dll
api-ms-win-core-localization-l1-2-0.dll   api-ms-win-crt-time-l1-1-0.dll
api-ms-win-core-memory-l1-1-0.dll         api-ms-win-crt-utility-l1-1-0.dll
api-ms-win-core-namedpipe-l1-1-0.dll      bin
api-ms-win-core-processenvironment-l1-1-0.dll  concrt140.dll
api-ms-win-core-processthreads-l1-1-0.dll  data
api-ms-win-core-processthreads-l1-1-1.dll  lib
api-ms-win-core-profile-l1-1-0.dll         msvcrt140.dll
api-ms-win-core-rtlsupport-l1-1-0.dll      payload
api-ms-win-core-string-l1-1-0.dll          scripts
api-ms-win-core-synch-l1-1-0.dll           tps
api-ms-win-core-synch-l1-2-0.dll           ucrtbase.dll
api-ms-win-core-sysinfo-l1-1-0.dll         vccorlib140.dll
api-ms-win-core-timezone-l1-1-0.dll        vcruntime140.dll
api-ms-win-core-util-l1-1-0.dll            xsetup
api-ms-win-crt-conio-l1-1-0.dll            xsetup.exe
api-ms-win-crt-convert-l1-1-0.dll
sdr@sdr-Samsung-DeskTop-System:~/install_vivado/Xilinx_Vivado_SDK_2017.4_1216_1$ sudo ./xsetup
```



## Welcome

We are glad you've chosen Xilinx as your platform development partner. This program can install the Vivado Design Environment, Software Development Kit and Documentation Navigator.

Supported operating systems for Vivado 2017.4 are:

- Windows 7.1: 64-bit
- Windows 10.0 Creators Update: 64-bit
- Red Hat Enterprise Linux 6.6-6.9: 64-bit
- Red Hat Enterprise Linux 7.2-7.3: 64-bit
- CentOS Linux 6.6-6.9: 64-bit
- CentOS Linux 7.2-7.3: 64-bit
- SUSE Enterprise Linux 11.4: 64-bit
- SUSE Enterprise Linux 12.2: 64-bit
- Ubuntu Linux 16.04.2 LTS: 64-bit - Additional library installation required

Note: This release requires upgrading your license server tools to the Flex 11.14.1 versions. Please confirm with your license admin that the correct version of the license server tools are installed and available, before running the tools.

Note: 32-bit machine support is now only available through HW Server standalone product installers

Note: This installation program will not install cable drivers on Linux. This item will need to be installed separately, with administrative privileges.

To reduce installation time, we recommend that you disable any anti-virus software before continuing.



## Accept License Agreements



Please read the following terms and conditions and indicate that you agree by checking the I Agree checkboxes.

**Xilinx Inc. End User License Agreement**

By checking "I AGREE" below, or OTHERWISE ACCESSING, DOWNLOADING, INSTALLING or USING THE SOFTWARE, YOU AGREE on behalf of licensee to be bound by the agreement, which can be viewed by [clicking here](#).

☒ **I Agree****WebTalk Terms And Conditions**

By checking "I AGREE" below, I also confirm that I have read [Section 13 of the terms and conditions](#) above concerning WebTalk and have been afforded the opportunity to read the WebTalk FAQ posted at <https://www.xilinx.com/products/design-tools/webtalk.html>. I understand that I am able to disable WebTalk later if certain criteria described in Section 13(c) apply. If they don't apply, I can disable WebTalk by uninstalling the Software or using the Software on a machine not connected to the internet. If I fail to satisfy the applicable criteria or if I fail to take the applicable steps to prevent such transmission of information, I agree to allow Xilinx to collect the information described in Section 13(a) for the purposes described in Section 13(b).

☒ **I Agree****Third Party Software End User License Agreement**

By checking "I AGREE" below, or OTHERWISE ACCESSING, DOWNLOADING, INSTALLING or USING THE SOFTWARE, YOU AGREE on behalf of licensee to be bound by the agreement, which can be viewed by [clicking here](#).

☒ **I Agree**

## Select Edition to Install



Select an edition to continue installation. You will be able to customize the content in the next page.

☐ Vivado HL WebPACK

Vivado HL WebPACK is the no cost, device limited version of Vivado HL Design Edition. Users can optionally add Model Composer and System Generator for DSP to this installation.

☒ **Vivado HL Design Edition**

Vivado HL Design Edition includes the full complement of Vivado Design Suite tools for design, including C-based design with Vivado High-Level Synthesis, implementation, verification and device programming. Complete device support, cable drivers and Documentation Navigator are included. Users can optionally add Model Composer to this installation.

☐ Vivado HL System Edition

Vivado HL System Edition is a superset of Vivado HL Design Edition with the addition of System Generator for DSP. Complete device support, cable drivers and Documentation Navigator are included. Users can optionally add Model Composer to this installation.

☐ Documentation Navigator (Standalone)



Xilinx Documentation Navigator (DocNav) provides access to Xilinx technical documentation both on the Web and on the Desktop. This is a standalone installation without Vivado Design Suite.

## Vivado HL Design Edition



Customize your installation by (de)selecting items in the tree below. Moving cursor over selections below provide additional information.

Vivado HL Design Edition includes the full complement of Vivado Design Suite tools for design, including C-based design with Vivado High-Level Synthesis, implementation, verification and device programming. Complete device support, cable drivers and Documentation Navigator are included. Users can optionally add Model Composer to this installation.

- 🔍  Design Tools
  - ☐ Vivado Design Suite
  - ☒ Software Development Kit (SDK)
  - ☒ DocNav
- 🔍  Devices
  - ☒ Production Devices
    - ☒ SoCs
    - ☒ 7 Series
    - ☒ UltraScale
    - ☒ UltraScale+
  - ☐ Engineering Sample Devices
- 🔍 ☒ Installation Options
  - ☐ NOTE: Cable Drivers are not installed on Linux. Please follow the instructions in UG973 to install Linux cable drivers
  - ☒ Acquire or Manage a License Key
  - ☒ Enable WebTalk for Vivado to send usage statistics to Xilinx (Always enabled for WebPACK license)
  - ☒ Enable WebTalk for SDK to send usage statistics to Xilinx

Download Size: NA  
Disk Space Required: 35.38 GB

[Reset to Defaults](#)

## Select Destination Directory



Choose installation options such as location and shortcuts.

### Installation Options

Select the installation directory

/opt/Xilinx



### Installation location(s)

/opt/Xilinx/Vivado/2017.4

/opt/Xilinx/SDK/2017.4

/opt/Xilinx/DocNav

### Disk Space Required

Download Size: NA

Disk Space Required: 35.38 GB

Disk Space Available: 717.77 GB

### Select shortcut and file association options

☒ Create program group entries

Xilinx Design Tools

☒ Create desktop shortcuts



## Installation Summary

### Edition: Vivado HL Design Edition

#### Devices

- Production Devices (SoCs, 7 Series, UltraScale, UltraScale+)

#### Design Tools

- Vivado Design Suite (Vivado)
- Software Development Kit (SDK) (SDK Core Tools, Compiler Tool Chains)
- DocNav

#### Installation Options

- Enable WebTalk for SDK to send usage statistics to Xilinx
- Enable WebTalk for Vivado to send usage statistics to Xilinx (Always enabled for WebPACK license)
- Acquire or Manage a License Key

#### Installation location

- /opt/Xilinx/Vivado/2017.4
- /opt/Xilinx/SDK/2017.4
- /opt/Xilinx/DocNav

#### Disk Space Required

- Download Size: NA
- Disk Space Required: 35.38 GB





## Installation Progress



Installing files, 0% completed.

Final Processing...

SDx<sup>™</sup>  
Environments



SDx Family of Development Environments  
for Systems and Software Engineers



## Installation Progress



✓ It took 15 minutes to install files.

✓ Done Final Processing.

UltraFAST™  
Design Methodology



Comprehensive Design Methodology Enables  
Accelerated and Predictable Design Cycles



License Manager



- Get License
  - Set Proxy
  - Obtain License
  - Load License
- Manage License
  - Manage License Search Paths
  - View License Status
- View System Information
- View Host Information

## Obtain License

Select one of the following options

- ☐ Start Now! 30 Day Trial (No Bitstream, No Support for SDx: SDAccel, SDSoc)
- ☐ Get Vivado or IP Evaluation Licenses
- ☐ Get Free ISE WebPACK, ISE/Vivado IP or PetaLinux Licenses
- ☒ Get My Full or Purchased Certificate-Based License

[Connect Now](#)[Save Link As...](#)

## Description of the above selected option

This selection will help you get your full or purchased Certificate-based licenses and start using the Xilinx tools. All purchased IP use Certificate-based licenses as do Xilinx tools, if purchased after April 2016. You will be taken to the Xilinx website where, if you have full or purchased licenses, you will see an account drop-down menu. In the appropriate license account, you can generate a license for all Xilinx software and IP you have purchased. After generation, the license file is sent to your e-mail. Once you have saved this file to your machine, click on the Load License selection to copy your .lic file to a default location.

# Vivado Design Suite - HLx Editions - 2017.4 Full Product Installation

## Important

We strongly recommend to use the web installers as it reduces download time and saves significant disk space.

Please see [Installer Information](#) for details.


 [Vivado HLx 2017.4: WebPACK and Editions - Windows Self Extracting Web Installer](#) (EXE - 51.3 MB)

MD5 SUM Value : 39677d35779915411487e5d89fe27ee8

 [Vivado HLx 2017.4: WebPACK and Editions - Linux Self Extracting Web Installer](#) (BIN - 100.7 MB)

MD5 SUM Value : 915928e0f33af22f1370acc6ac32c2b5

Vivado HLx 2017.4: All OS  
installer Single-File Download

 [Vivado HLx 2017.4: All OS Installer Single-File Download](#) (TAR/GZIP - 16.17 GB)

MD5 SUM Value : 5a1bb63f893f0039e34c9f412dd063a9

Download Includes

Vivado Design Suite HLx Editions (All Editions)

Download Type

Full Product Installation

Last Updated

Dec 20, 2017

Answers

[2017.x - Vivado Known Issues](#)

Documentation

[2017.4 - Release Notes](#)

Enablement

[License Solution Center](#)



All ▾

Applications

Products

Developer Zone

[Xilinx - Adaptable. Intelligent.](#) > [Support](#) > Licensing Solution Center

## Licensing Solution Center

What type of product license help do you need?

### Obtain a license for Free or Evaluation product

- **Free or Evaluation Product Licenses** - After completing the installation of Vivado, SDx or ISE Design Suite, the Xilinx License Configuration Manager (XCLM) will start automatically and guide you through the licensing process.

You may also go directly to the [Xilinx Product Licensing Site](#) to obtain licenses for free or evaluation products if you decided to skip this step during product installation.

### Obtain a license for Purchased product

- **Purchased Products** - If you have purchased Vivado, SDx or ISE Design Suite products or IP Cores, a notification e-mail with licensing instructions has been sent to the Account Administrator for your site. Please locate this notification and follow the instructions to obtain your license for purchased products.

Visit the [Xilinx Product Licensing Site](#) to generate a License Key.

### Obtain a license for Legacy IP Core Products

- **License keys for IP cores shipped after Vivado, SDx or ISE v6.3 or EDK v6.3** - If your IP core product is in warranty, the [Xilinx Product Licensing Site](#) will automatically generate a license key file that enables both the current release IP version as well as prior versions of the core, up to the IP versions shipped against Vivado, SDx or ISE v6.3 and EDK v6.3.

### Redeem an Vivado, SDx or ISE Design Suite or IP Core product voucher code

- Most Xilinx and Xilinx partner board kits with support for Vivado, SDx or ISE Design Suite version 11 or later contain a product voucher that may be redeemed for associated Vivado, SDx or ISE Design Suite tools and/or IP Core licenses.

**City \*****State \***

Please use 2-letter code for your [US state](#) or [Canadian province](#).

**Country \*****Zip Code \*****Phone****Job Function \*****Primary Market \***

For more information about how we process your personal information, please see our [privacy policy](#).

[Next](#)

Account:

 [Help](#)[Create New Licenses](#)[Manage Licenses](#)[Orders](#)[Manage Users](#)

Have a Voucher to Redeem? ?

XXXX-XXXXXX-XXXX-XXXXXX

[Redeem Now](#)

Evaluation and No Charge Cores ?

Search the **Evaluation** and **No Charge** cores catalog and add specific cores to table below[Search Now](#)

## Create a New License File for Account:

Create a new license file by making your product selections from the table below. Floating and Node-Locked licenses cannot be combined in the same license file. ?

### Certificate Based Licenses

Product	Type	License	Available Seats	Status	Subscription End Date
<input type="checkbox"/> <a href="#">Model Composer : 90-day Evaluation License</a>	Certificate - Evaluation	Node / Floati...	1/1	Current	90 days
<input type="checkbox"/> <a href="#">Vivado Design Suite: 30-Day Evaluation License</a>	Certificate - Evaluation	Node	1/1	Current	30 days
<input type="checkbox"/> <a href="#">SDSoC Environment, 60 Day Evaluation License</a>	Certificate - Evaluation	Node / Floati...	1/1	Current	60 days
<input checked="" type="checkbox"/> <a href="#">Vivado Design Suite: HL WebPACK 2015 and Earlier License</a>	Certificate - No Charge	Node	1/1	Current	None
<input checked="" type="checkbox"/> <a href="#">ISE WebPACK License</a>	Certificate - No Charge	Node	1/1	Current	None
<input checked="" type="checkbox"/> <a href="#">Xilinx MicroBlaze/All Programmable SoC Software Development Kit – Standalone</a>	Certificate - No Charge	Node	1/1	Current	None
<input type="checkbox"/> <a href="#">PetaLinux Tools License</a>	Certificate - Evaluation	Node	1/1	Current	365 days
<input type="checkbox"/> <a href="#">PetaLinux Tools License, Floating License</a>	Certificate - Evaluation	Floating	1/1	Current	365 days
<input type="checkbox"/> <a href="#">Vivado HLS Evaluation License</a>	Certificate - Evaluation	Node	1/1	Current	30 days

[Generate Floating License](#)[Generate Node-Locked License](#)

What is the difference between a floating and a node license? ?





Have a voucher to redeem?  
XXXX-XXXXXX-XXXX-XXXX

enter voucher code



Fields marked with an asterisk \* are required.

## 1 PRODUCT SELECTION

Product  
Selections \*

	Product	Type	Available Seats	Subscription End Date	Requested Seats	Borrowed Seats
<input checked="" type="checkbox"/>	Xilinx MicroBlaze/All ...	No Charge	1/1	None	1	
<input checked="" type="checkbox"/>	ISE WebPACK License	No Charge	1/1	None	1	
<input checked="" type="checkbox"/>	Vivado Design Suite: ...	No Charge	1/1	None	1	

Add a host...


1. Host Name ? :
2. Operating System ? :  Linux 64-bit
3. Host ID Type ? :  Ethernet MAC
4. Host ID Value ? :



## 2 SYSTEM

License

Host ID \* ?

 LinuxHome - Linux 64-bit - Ethernet MAC

Cancel

Add

## 3 COMMENTS

Comments ?

Next

[Cancel](#)

### Create a New License

Create a new license file  
in the same license file. ?

### Certificate Based License

☐ Model Composer : 90-day Evaluation

☐ Vivado Design Suite: 30-Day Evaluation

☐ SDSoc Environment, 60 Day Evaluation

☒ Vivado Design Suite: HL WebPACK License

☒ ISE WebPACK License

☒ Xilinx MicroBlaze/All Program

☐ PetaLinux Tools License

☐ PetaLinux Tools License, Floating

☐ Vivado HLS Evaluation License

Generate Floating License

What is the difference between



```
Terminal File Edit View Search Terminal Help
sdr@sdr-Samsung-DeskTop-System:~/install_vivado/Xilinx_Vivado_SDK_2017.4_1216_1$ ifconfig
lo          Link encap:Local Loopback
            inet addr:127.0.0.1  Mask:255.0.0.0
            inet6 addr: ::1/128 Scope:Host
            UP LOOPBACK RUNNING  MTU:65536  Metric:1
            RX packets:4732 errors:0 dropped:0 overruns:0 frame:0
            TX packets:4732 errors:0 dropped:0 overruns:0 carrier:0
            collisions:0 txqueuelen:1000
            RX bytes:480746 (480.7 KB)  TX bytes:480746 (480.7 KB)

wlp4s0      Link encap:Ethernet  HWaddr ac:b5:7d:94:3e:af
            inet addr:192.168.219.138  Bcast:192.168.219.255  Mask:255.255.255.0
            inet6 addr: fe80::ad70:90c5:e7cb:4f71/64 Scope:Link
            UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
            RX packets:151322 errors:0 dropped:0 overruns:0 frame:0
            TX packets:90872 errors:0 dropped:0 overruns:0 carrier:0
            collisions:0 txqueuelen:1000
            RX bytes:197652955 (197.6 MB)  TX bytes:11839626 (11.8 MB)

sdr@sdr-Samsung-DeskTop-System:~/install_vivado/Xilinx_Vivado_SDK_2017.4_1216_1$
```



Have a voucher to re  
XXXX-XXXXXX-XXXX-XX

enter voucher code

## Create a New License

Create a new license file b  
in the same license file. ?

## Certificate Based Licen

☐ Model Composer : 90-day Eva

☐ Vivado Design Suite: 30-Day E

☐ SDSoc Environment, 60 Day

☒ Vivado Design Suite: HL WebF

☒ ISE WebPACK License

☒ Xilinx MicroBlaze/All Program

☐ PetaLinux Tools License

☐ PetaLinux Tools License, Floa

☐ Vivado HLS Evaluation Licens

Generate Floating Licens


What is the difference bet

Fields marked with an asterisk \* are required.

## 1 PRODUCT SELECTION

Product Selections *	Product	Type	Available Seats	Subscription End Date	Requested Seats	Borrowed Seats
<input checked="" type="checkbox"/>	Xilinx MicroBlaze/All ...	No Charge	1/1	None	1	
<input checked="" type="checkbox"/>	ISE WebPACK License	No Charge	1/1	None	1	
<input checked="" type="checkbox"/>	Vivado Design Suite: ...	No Charge	1/1	None	1	

## 2 SYSTEM INFORMATION

License	Node
Host ID * ?	 linuxHome - Linux 64-bit - Ethernet - acb57d943eaf

## 3 COMMENTS

Comments ?	
------------	--

Next

[Cancel](#)



How do I create a license file?

<http://www.xilinx.com>

How do I get more help?

<http://www.xilinx.com/support.html>

Regards,

Xilinx Customer Service

This email was sent by:

Xilinx, Inc.

2100 Logic Dr.


San Jose, CA 95134-3400

United States of America

Xilinx does not rent, sell or lease customer information. We respect your right to privacy. View our policy at [www.xilinx.com/legal.htm](http://www.xilinx.com/legal.htm).

...

[메일 내용 잘림] [전체 메일 보기](#)



Xilinx.lic

How do I create a license file?

<http://www.xilinx.com/cgi-bin/docs/rdoc?v=latest;d=iil.pdf;a=CreateLicenseKeyFile>

How do I get more help?

<http://www.xilinx.com>

Regards,

Xilinx Customer Se

This email was sen

Xilinx, Inc.

2100 Logic Dr.

San Jose, CA 951

United States of Ar


Xilinx does not rent


...

[메일 내용 잘림] [전](#)



Xilinx.lic





License Manager



## Get License

- Set Proxy
- Obtain License
- Load License

## Manage License

- Manage License Search Paths
- View License Status
- View System Information
- View Host Information

## Load License

## Certificate Based Licenses

Click the 'Copy License' button to copy a certificate-based license (.lic file) into the \$HOME/.Xilinx directory. Xilinx applications automatically detect valid, node-locked licenses (\*.lic) residing in the \$HOME/.Xilinx directory.

[Copy License...](#)

# VIVADO.


## License Manager

- Get License
  - Set Proxy
  - Obtain License
  - Load License**
- Manage License
  - Manage License Search Paths
  - View License Status**
- View System Information
- View Host Information

### Load License

#### Certificate Based Licenses

Click the 'Copy License' button to copy a certificate-based license (.lic file) into directory. Xilinx applications automatically detect valid, node-locked licenses in the \$HOME/.Xilinx directory.



# VIVADO. License Manager

- ▲ Get License
  - ⚙ Set Proxy
  - 📄 Obtain License
  - ⬇ Load License
- ▲ Manage License
  - ✎ Manage License Search Paths
  - ✓ View License Status
- ▲ View System Information
  - 📄 View Host Information

## Load License

### Certificate Based Licenses

Click the 'Copy License' button to copy a certificate-based license (.lic file) directory. Xilinx applications automatically detect valid, node-locked licenses in the \$HOME/.Xilinx directory.

[Copy License...](#)

### Vivado License Manager



License installation was successful: /root/.Xilinx/Xilinx.lic

OK



Terminal File Edit View Search Terminal Help

```
sdr@sdr-Samsung-DeskTop-System:~/install_vivado/Xilinx_Vivado_SDK_2017.4_1216_1$ source /opt/Xilinx/DocNav/.settings64-DocNav.sh
sdr@sdr-Samsung-DeskTop-System:~/install_vivado/Xilinx_Vivado_SDK_2017.4_1216_1$ source /opt/Xilinx/Vivado/2017.4/.settings64-Vivado.sh
sdr@sdr-Samsung-DeskTop-System:~/install_vivado/Xilinx_Vivado_SDK_2017.4_1216_1$ source /opt/Xilinx/SDK/2017.4/.settings64-SDK_Core_Tools.sh
sdr@sdr-Samsung-DeskTop-System:~/install_vivado/Xilinx_Vivado_SDK_2017.4_1216_1$ ldd /opt/Xilinx/Vivado/2017.4/bin/unwrapped/linux64.o/vivado
        linux-vdso.so.1 => (0x00007ffe5c25c000)
        libtcmalloc.so.4 => not found
        libboost_signals.so => not found
        librdi_common.so => not found
        librdi_commonmain.so => not found
        libstdc++.so.6 => /usr/lib/x86_64-linux-gnu/libstdc++.so.6 (0x00007fc7c1987000)
        libgcc_s.so.1 => /lib/x86_64-linux-gnu/libgcc_s.so.1 (0x00007fc7c1771000)
        libc.so.6 => /lib/x86_64-linux-gnu/libc.so.6 (0x00007fc7c13a7000)
        libm.so.6 => /lib/x86_64-linux-gnu/libm.so.6 (0x00007fc7c109e000)
        /lib64/ld-linux-x86-64.so.2 (0x00007fc7c1d09000)
sdr@sdr-Samsung-DeskTop-System:~/install_vivado/Xilinx_Vivado_SDK_2017.4_1216_1$
```



```
sdr@sdr-Samsung-DeskTop-System:~/install_vivado/Xilinx_Vivado_SDK_2017.4_1216_1$ objdump -p /opt/Xilinx/Vivado/2017.4/bin/unwrapped/lnx64.o/vivado
```

```
/opt/Xilinx/Vivado/2017.4/bin/unwrapped/lnx64.o/vivado:      file format elf64-x86-64
```

#### Program Header:

PHDR	off	0x0000000000000040	vaddr	0x00000000000040040	paddr	0x00000000000040040	align	2**3
	filesz	0x00000000000001c0	memsz	0x00000000000001c0	flags	r-x		
INTERP	off	0x0000000000000200	vaddr	0x000000000000400200	paddr	0x000000000000400200	align	2**0
	filesz	0x000000000000001c	memsz	0x000000000000001c	flags	r--		
LOAD	off	0x0000000000000000	vaddr	0x000000000000400000	paddr	0x000000000000400000	align	2**21
	filesz	0x00000000000003814	memsz	0x00000000000003814	flags	r-x		
LOAD	off	0x00000000000003818	vaddr	0x000000000000603818	paddr	0x000000000000603818	align	2**21
	filesz	0x0000000000000628	memsz	0x0000000000000630	flags	rw-		
DYNAMIC	off	0x00000000000003b00	vaddr	0x000000000000603b00	paddr	0x000000000000603b00	align	2**3
	filesz	0x0000000000000230	memsz	0x0000000000000230	flags	rw-		
NOTE	off	0x000000000000021c	vaddr	0x00000000000040021c	paddr	0x00000000000040021c	align	2**2
	filesz	0x0000000000000020	memsz	0x0000000000000020	flags	r--		
EH_FRAME	off	0x00000000000003244	vaddr	0x000000000000403244	paddr	0x000000000000403244	align	2**2
	filesz	0x00000000000000fc	memsz	0x00000000000000fc	flags	r--		
STACK	off	0x0000000000000000	vaddr	0x0000000000000000	paddr	0x0000000000000000	align	2**4
	filesz	0x0000000000000000	memsz	0x0000000000000000	flags	rw-		

#### Dynamic Section:

NEEDED	libtcmalloc.so.4
NEEDED	libboost_signals.so
NEEDED	librdi_common.so
NEEDED	librdi_commonmain.so
NEEDED	libstdc++.so.6
NEEDED	libgcc_s.so.1
NEEDED	libc.so.6
INIT	0x000000000000402158
FINI	0x000000000000402fbc
INIT_ARRAY	0x000000000000603818
INIT_ARRAYSZ	0x0000000000000010
FINI_ARRAY	0x000000000000603828
FINI_ARRAYSZ	0x0000000000000008
HASH	0x000000000000400240
STRTAB	0x000000000000400cf8

```
Terminal File Edit View Search Terminal Help
sdr@sdr-Samsung-DeskTop-System:~/install_vivado/Xilinx_Vivado_SDK_2017.4_1216_1$ cd /opt/Xilinx/V
ivado/2017.4/data/xicom/cable_drivers/lin64/install_script/install_drivers/
sdr@sdr-Samsung-DeskTop-System:/opt/Xilinx/Vivado/2017.4/data/xicom/cable_drivers/lin64/install_s
cript/install_drivers$ sudo ./install_drivers
[sudo] password for sdr:
INFO: Installing cable drivers.
INFO: Script name = ./install_drivers
INFO: HostName = sdr-Samsung-DeskTop-System
INFO: Current working dir = /opt/Xilinx/Vivado/2017.4/data/xicom/cable_drivers/lin64/install_scri
pt/install_drivers
INFO: Kernel version = 4.15.0-36-generic.
INFO: Arch = x86_64.
USB udev file exists and will not be updated.
--File /etc/udev/rules.d/52-xilinx-ftdi-usb.rules does not exist.
--File version of /etc/udev/rules.d/52-xilinx-ftdi-usb.rules = 0000.
--Updating rules file.
--File /etc/udev/rules.d/52-xilinx-pcusb.rules exists.
--File /etc/udev/rules.d/52-xilinx-pcusb.rules version = 0002
--File 52-xilinx-pcusb.rules exists.
--File 52-xilinx-pcusb.rules version = 0002
--File 52-xilinx-pcusb.rules is already updated.

INFO: Digilent Return code = 0
INFO: Xilinx Return code = 0
INFO: Xilinx FTDI Return code = 0
INFO: Return code = 0
INFO: Driver installation successful.
CRITICAL WARNING: Cable(s) on the system must be unplugged then plugged back in order for the dri
ver scripts to update the cables.
sdr@sdr-Samsung-DeskTop-System:/opt/Xilinx/Vivado/2017.4/data/xicom/cable_drivers/lin64/install_s
cript/install_drivers$ █
```

```
Terminal File Edit View Search Terminal Help
sdr@sdr-Samsung-DeskTop-System:/opt/Xilinx/Vivado/2017.4/data/xicom/cable_driver
s/lin64/install_script/install_drivers$ vi ~/.bashrc
```

```
102 # See /usr/share/doc/bash-doc/examples in the bash-doc package.
103
104 if [ -f ~/.bash_aliases ]; then
105     . ~/.bash_aliases
106 fi
107
108 # enable programmable completion features (you don't need to enable
109 # this, if it's already enabled in /etc/bash.bashrc and /etc/profile
110 # sources /etc/bash.bashrc).
111 if ! shopt -oq posix; then
112     if [ -f /usr/share/bash-completion/bash_completion ]; then
113         . /usr/share/bash-completion/bash_completion
114     elif [ -f /etc/bash_completion ]; then
115         . /etc/bash_completion
116     fi
117 fi
118
119 # Enable Vivado 2015 & Petalinux 2015
120 #source /home/sdr/petalinux_zynq/petalinux-v2015.4-final/settings.sh
121 #source /opt/Xilinx/Vivado/2015.4/settings64.sh
122
123 # Enable Vivado 2017
124 source /opt/Xilinx/Vivado/2017.4/settings64.sh
```

```
INFO: Script name = ./install_drive
INFO: HostName = sdr-Samsung-DeskTo
INFO: Current working dir = /opt/Xi
pt/install_drivers
INFO: Kernel version = 4.15.0-36-ge
INFO: Arch = x86_64.
USB udev file exists and will not b
--File /etc/udev/rules.d/52-xilinx-
--File version of /etc/udev/rules.d
--Updating rules file.
--File /etc/udev/rules.d/52-xilinx-
--File /etc/udev/rules.d/52-xilinx-
--File 52-xilinx-pcusb.rules exists
--File 52-xilinx-pcusb.rules versio
--File 52-xilinx-pcusb.rules is alr
```

```
INFO: Digilent Return code = 0
INFO: Xilinx Return code = 0
INFO: Xilinx FTDI Return code = 0
INFO: Return code = 0
INFO: Driver installation successfu
CRITICAL WARNING: Cable(s) on the s
ver scripts to update the cables.
sdr@sdr-Samsung-DeskTop-System:/opt
cript/install_drivers$ vivado
CRITICAL WARNING: [Common 17-183] F
n of directory '/opt/Xilinx/Vivado/
rivers'. You should restart the app
CRITICAL WARNING: [Common 17-183] F
n of directory '/opt/Xilinx/Vivado/
rivers'. You should restart the app
```

```
***** Vivado v2017.4 (64-bit)
**** SW Build 2086221 on Fri Dec
**** IP Build 2085800 on Fri Dec
** Copyright 1986-2017 Xilinx,
```

```
start_gui
```

