

TROUBLESHOOTING GUIDE

When an error code appears on the display screen, the system will stop running and will only continue to run when the error is fixed.

Function of automatic "recovery"

Turn off the power and disconnect the power cord. Wait for 10 seconds, then reconnect the power cord to the power source and turn on the device again. If there is an error code, please contact customer service to resolve the problem.

Code	Error	Solving
E1	Failure of booster pump	Please contact the customer service.
E2	Malfunction of single float water level control switch	Please contact the customer service.
E3	Temperature sensor malfunction	Please contact the customer service.
E6	Malfunction of water outlet pump	Please contact the customer service.
E7	Booster pump operates continuously for more than 2 hours (or filter clogged)	Turn on the equipment again. If the error code reappears once more, please contact the customer service.
E8	Double float water level control switch malfunction	Please contact the customer service.
Others		Please contact the customer service.