

Options

1. Speed Source – GPS

- Use speed from AOG.

2. Speed Source – Simulated Speed

- Simulate a constant speed.

3. Speed Source – Wheel Sensor

- Enter the module ID and GPIO pin used to sense speed. Enter the calibration number in pulses per mile or pulses per kilometer. Press the up arrow to send configuration data to the module (also sent when saved). Use the calibration screen to calculate the calibration number.