

Rate Map

1 Copy

5 Import

8 Save Image

Enable 11 VR


12 Full Screen

13 Zones

14 Sat View

15 Rate Data

Zone


2 

3

4 29.3

6 


7

9 

10 Color

Product A	56
Product B	27
Product C	16
Product D	0

^



▼

©2025 Microsoft Corporation, ©2025 NAVTEQ, ©2025 Image courtesy of NASA

1. Copy rate map from another job.
2. Edit rate zone.
3. Name of zone.
4. Area of zone in acres or hectares.
5. Import
 - Press the Import button to open the Import form. Load an alternative type of shape file using the up-arrow on the Import form. The form will list the RC attributes on the left. Use the drop-down box to the right of each RC attribute to cross reference from the alternative file attributes. Use the down-arrow on the Import form to save a new RC shape file with these cross referenced attributes.
6. Delete zone.
7. Product rates.
8. Save an image of the map to file.
9. Save zone changes.
10. Zone color.
11. Enable VR
 - Enable variable rate control. Each product uses variable rate control. All zones must define a rate for each product used.
12. Full screen view.
13. Show zones overlay.
14. Show satellite view.
15. Show rate data overlay.