

Product Settings

1. Enable product.
2. Rate Sensor Location
 - Module ID, unique ID # of each module, 0-7
 - Sensor ID, unique sensor ID in each module, 0-1
3. Minimum UPM
 - Fixed Value, minimum UPM flow rate acceptable
 - By Speed, adjust the minimum UPM base on speed
4. Off-Rate Alarm
 - the % error in rate where an alarm will sound
5. Default Product
 - product displayed at start up
6. Bump Buttons
 - show the rate up/down buttons on the Large Screen
7. Scale Weight
 - show the scale weight screen