

1. Rate Sensor Location

a. Module ID

- unique ID # of each module, 0-7

b. Sensor ID

- unique sensor ID in each module, 0-1

2. Minimum UPM

a. Fixed Value

- minimum UPM flow rate acceptable

b. By Speed

- adjust the minimum UPM base on speed

3. Default Product

- product displayed at start up

4. On Screen

- display on the Large Screen

5. Bump Buttons

- show the rate up/down buttons on the Large Screen

6. Scale Weight

- show the scale weight screen

7. Off-Rate Alarm

- the % error in rate where an alarm will sound