

Product Settings

1. Rate Sensor Location
 - a. Module ID
 - unique ID # of each module, 0-7
 - b. Sensor ID
 - unique sensor ID in each module, 0-1
2. Minimum UPM
 - a. Fixed Value
 - minimum UPM flow rate acceptable
 - b. By Speed
 - adjust the minimum UPM base on speed
3. Default Product
 - product displayed at start up
4. On Screen
 - display on the Large Screen
5. Bump Buttons
 - show the rate up/down buttons on the Large Screen
6. Scale Weight
 - show the scale weight screen
7. Off-Rate Alarm
 - the % error in rate where an alarm will sound