

## **Troubleshooting**

### **No Relays:**

1. Is module config for board and relay type correct?
2. Subnet set in app? Uploaded to module?
3. Section count and width set?
4. Is Auto on?
5. Section assigned to relay?
6. Switch assigned to section?
7. If auto on, sensor counts/unit and base rate are needed.

### **No UPM:**

1. Check speed.
2. Check working width.
3. Check sensor control settings.
4. AOG connected?
5. Module connected?
6. Check sensor counts/unit.
7. Check base rate.
8. Did the control values get sent to the module?
9. Control type, is it a valve or motor?
10. Connector fully plugged in?
11. Up to date version of module firmware?

### **No rate adjust:**

1. In manual the master switch must be on.
2. Minimum pwm too low?

### **Motor won't shut off:**

1. Minimum pwm should be 0.
2. Master override on?

### **After Updating firmware:**

1. Resend subnet.
2. Resend module config settings.